






Montageanleitung

					
1-1 x2	2-1 x4	2-2 x4	2-3 x4	2-4 x4	2-5 x4
	 M6x35				
3-1 x1	3-2 x2	3-3 x1	3-4 x1	3-5 x1	3-6 x2
 M6x20					
3-7 x2	4-1 x2	4-2 x1	4-3 x1	4-4 x1	4-5 x3
				 M6	
5-1 x1	5-2 x1	5-3 x6	5-4 x6	5-5 x6	5-6 x6
					
5-7 x6	5-8 x6				


1



2




3



4

Wenn die Öffnungsrichtung der Tür geändert werden muss, gehen Sie bitte wie folgt vor.
Wenn nicht, können Sie diesen Schritt überspringen.



5

